
Press "SET-UP"
GAS-Monitor
Go to Back Page
Analog/Relay
Analog
Select Analog Units
Gas A Analog min conc.
Gas A Analog max conc.
Repeat for Remaining Filters
Returns to Previous Head
Select Relay Output Mode
Gas Mode
Returns to Previous Head
Channel Mode
Check and/or change set-up for Channel 1
NO
YES
Select Relay Number for Channel 1:
Select Alarm Limit
Check and/or change set-up for channel 2
Repeat for Remaining Channels
Returns to Previous Head
MULTIPOINT SAMPLER
Gas Monitor System Controller
NO
Returns to Previous Head
YES
Use channel 1 Yes/No
Use channel 2 Yes/No
Use channel 24 Yes/No
Returns to Previous Head