


Press "SET-UP"

MEASUREMENT



FORMAT

CONFIGURATION


Monitoring Task




Environment




System



Units



Filters



* Remember to partial reset 1314/1412 if any parameter in this branch is changed